

**Accord<sup>®</sup>**

## End Clip Projection Mounting using CMT

**Assembly  
Instructions**

1. Cut **CMT** to length.
2. Apply **SBEC-VT** to each side of **CMT**, peel tape liner and join **SBEC** to tape on center flange.
3. Apply **#4408** foam tape to **SBEC**, peel tape liner and join other **SBEC** carefully aligning before pressure is applied.
4. Assemble one sign face to the **CMT** assembly and snap together the two **SBEC**'s.
5. Drill a 1/8" hole in center multi-clip segment. Bend wire to match hole in **CMT** assembly and End Clip. Insert wire into drilled hole and push opposite end into multi-clip hole through tape. This will ensure final assembly will not come apart after installation.
6. Snap on additional SignBand.

