

## PSV Letters

## Application Instructions

APCO PSV Letters are coated with a pressure sensitive backing. They are applied at the touch. Pre-spaced and pre-aligned legends, rather than individual letters, are applied as "one piece," making application quick and easy.



1. Clean application surface with window cleaner and dry thoroughly. Temperature of surface should be a minimum of 60°F for Scotchlite® and 50°F for Reflective Scotchlite® material.



2. Position legend on surface and hold into place with small pieces of masking tape at the bottom edge. Then apply a "hinge" of masking tape along the entire bottom edge. (If legend is applied to a vertical surface, hinge at top.)



3. Cut legend into 3" sections being careful not to damage the letters.



4. Raise each section up over the "hinge" and carefully remove the liner backing.



5. Using the plastic squeegee, press the application tape to the surface by burnishing away from the hinge.



6. When burnishing is complete, the application tape, along with the masking tape hinge, is removed by pulling back at 180° angle. Burnish the legend once again lightly after the removal of the application tape.