

# FullView™ Retention Clip

## Installation Instructions

The Retention Clip was designed to retain clear lens for larger sized FullView product. The clip will press the Clear Lens flush to the printed material displayed when properly installed. Follow the simple steps below:

Before installing, be sure signs are affixed to wall surface and insert or display material is contained by Clear Lens. Note that one clip should be placed center of top and bottom of sign as shown:

1. Slide retention clip under sign frame as shown in fig. 1.
2. Push toward frame center as shown in fig. 2 to snap clip over frame and compress clear lens.
3. Install clips to top and bottom of each sign. See detail in figures 3 showing bottom clip installed and 4 showing top clip installed.




Fig. 1




Fig. 2



Fig. 3



Fig. 4

### FullView Retention Clip (FVRC)

